

EL-PIAST

MICRO-N (N-E-_)

Page: 1


Option
3.10 24VAC
3.10 GND
24VAC
GND
B3
PT1000
SHIELD
YNE
GND
0-10
RS1U1
A
B
GND
S1F
1UA1
1S1F
S4F
GND PT2 GND AO2 AO1 B– A+ B– A+ DI1 DI2 DI3
RS1 RS2
ELP12R12–II
N12
PT1 GND VAC GND Re1 Re1 Re2 Re2 Re3 Re4 Re5 COM
24VAC
GND
24VAC 3.1
GND 3.1
B1
PT1000
ENE
1Y1
GND 24VAC POWER S
1S1H
1S2H
Option